



Art. 160.1005

Art.-Nr.	Beschreibung	Description	Menge Qty.
160.1005-R001P	Mutter	Nut	6
160.1005-R002P	Unterlegscheibe	Washer	2
160.1005-R003P	Vordere Rolle	Front wheel	2
160.1005-R004P	Lager für vordere Rolle	Front wheel bushing	2
160.1005-R005P	Vorderachse	Front wheel axle	1
160.1005-R006P	Schraube	Screw	4
160.1005-R007P	Unterlegscheibe	Washer	4
160.1005-R008P	Endanschlagsbolzen	Limit rod	1
160.1005-R009P	Handgriff	Handle	2
160.1005-R010P	Schraube	Screw	4
160.1005-R011P	Unterlegscheibe	Washer	8
160.1005-R012P	Unterlegscheibe	Washer	4
160.1005-R013P	Schraube	Screw	10
160.1005-R014P	Lenkrolle	Rear wheel	2
160.1005-R015P	Lenkrollen Aufnahme	Rear wheel	2
160.1005-R016P	Umlenkrolle	Roller	2
160.1005-R017P	Gummipuffer	Limit ring	2
160.1005-R018P	Sicherungsring	Gasket ring	1
160.1005-R019P	Umlenkrolle	Handle socket roller	1
160.1005-R020P	Achse	Axle	1
160.1005-R021P	Lenkstangenaufnahme	Handle socket	1
160.1005-R022P	Bolzen	Pin	1
160.1005-R023P	Schraube	Screw	1
160.1005-R024P	Hydraulikeinheit	Hydraulic power unit	1

Art.-Nr.	Beschreibung	Description	Menge Qty.
160.1005-R025P	Untere Lenkstange	Lower handle	1
160.1005-R026P	Schaumstoffschutz für Lenkstange	Handle sleeve	1
160.1005-R027P	Bolzen	Pin	1
160.1005-R028P	Obere Lenkstange	Upper handle	1
160.1005-R029P	Feder	Pressure spring	2
160.1005-R030P	Bolzen	Pin	1
160.1005-R031P	Sicherungsring	Gasket ring	2
160.1005-R032P	Verbindungstrebe	Connecting rod	1
160.1005-R033P	Hubarm	Lifting arm	1
160.1005-R034P	Schraube	Screw	1
160.1005-R035P	Aufnahmeteller	Saddle	1
160.1005-R036P	Sicherungsring	Gasket ring	2
160.1005-R037P	Schraube	Screw	4
160.1005-R038P	Verbindungstrebe	Long connecion rod	2
160.1005-R039P	Gewindeeinsatz	Long connecion rod axle	2
160.1005-R040P	Verstärkungsplatte	Rear stop iron	2
160.1005-R041P	Schraube	Screw	2
160.1005-R042P	Rahmen links	Left frame	1
160.1005-R043P	Achse	Axle	1
160.1005-R044P	Abdeckung	Cover board	1
160.1005-R045P	Schraube	Screw	4
160.1005-R046P	Gummiteller	Rubber pad	1
160.1005-R047P	Rahmen rechts	Right frame	1